

IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

APPLICATION FOR PATENT

TITLE:

REDUNDANT SINGLE EVENT UPSET SUPPRESSION SYSTEM

INVENTOR:

James R. Hoff

A UNITED STATES CITIZEN

Attorney Docket No.: 1000-1349

EXPRESS MAIL NO.: EU779131066US

REDUNDANT SINGLE EVENT UPSET SUPPRESSION SYSTEM

GOVERNMENT INTEREST

[001] The United States Federal Government has right to this invention pursuant to Contract No. **DE-AC02-76CH03000** between Universities Research Corporation and the United States Department of Energy.

FIELD OF THE INVENTION

[002] The present invention is generally related to integrated circuit design. More particularly, the present invention is related to methods and systems preventing single event upset in integrated circuits and memory cells. Additionally, the present invention is related to methods and systems preventing upset in integrated circuits and memory cells by utilizing a design of redundant single event upset tolerant registers.

BACKGROUND

[003] The effects of radiation on integrated circuits have been known for over thirty years. These effects can be broken down into two broad categories. The first category is "total dose effects" in which an integrated circuit gradually deteriorates due to the accumulated effect of all the damage done to the crystal structure by the many, many particles incident on it. In the 1980s and early 90s, these effects were mitigated by special "rad hard" processes. These rad hard processes were expensive because they required special processing steps to fabricate. Fortunately, the unstoppable drive towards smaller and smaller transistor sizes has allowed those skilled in the art to develop "radiation tolerant" layout techniques in deep sub-micron processes that are the cornerstone of modern silicon fabrication. These radiation tolerant layout techniques mitigate total dose effects at least as well if not better than the "rad hard" processes ever did. Moreover, the fact that radiation tolerant layout techniques use standard

silicon processing makes them inexpensive and available to everyone. For these reasons, total dose harness can be viewed as a solved problem, though radiation tolerant layout techniques place restrictions on a designer's freedom, most notably on his or her ability to ratio transistors at will.

[004] The second category of radiation effects is "single event effects" in which a single particle, either through its exceptionally high energy or through the accuracy of its trajectory through a semiconductor, is capable of affecting a circuit. Single event effects are varied, and most of the effects can be mitigated by proper layout techniques. One type of single-event effect in particular requires more effort to eliminate, however, and that is the single event upset or SEU in which the contents of a memory cell are altered by an incident particle.

[005] SEUs belong to a class of errors called "soft-errors" in that they simply reverse the state of a memory. They do not, in and of themselves, damage a circuit. This does not mean, however, that they can be ignored. Single event upsets in a computer alter the computer's internal state, "confusing" the computer and potentially crashing the system. In the case of computers that control satellite systems or machinery, this can be catastrophic. Single event upsets in medical imaging and scientific experiment can result in noisy signals and data loss, requiring higher intensities and longer exposure times to overcome the noise.

[006] A number of SEU-hardening techniques have been employed in the past. These techniques can be divided into three types. The first type is technology hardening in which changes are made to the fabrication of the chip such that critical charges necessary for single-event upset to occur do so with reduced frequency. One example of technology hardening is Silicon-on-Sapphire or SOS in which the chip is grown on an insulator to reduce the charge build-up due to incident particles. The second type of SEU hardening is passive hardening in which passive components like capacitors or resistors are added to a circuit to

either slow it down or to increase the charge required to reverse its state. Finally, the third type of SEU hardening is design hardening in which redundancy and feedback are added to a circuit to make it immune to single events.

[007] Technology hardening is not generally viable commercially because the silicon industry has become accustomed to its fabrication methods for which it has spent billions of dollars to develop. Passive hardening is not efficient. Although it is a workable solution, it is a deliberate slowing-down of information processing, which is at odds with the clear industry objective to speed up processing. Moreover, passive hardening is not scalable, therefore fabrication changes from 0.5 μ m to 0.25 μ m to 0.18 μ m requires passive hardening redesign and re-testing. Design hardening, on the other hand, is limited only by the creativity of the designers.

[008] Computer memory comes in different forms. The two most common categories are SRAM and DRAM. Both are ubiquitous in modern digital design. DRAM or Dynamic Random Access Memory is smaller and generally slower. They are used for mass storage and their contents must continually be refreshed or the values they hold will be lost. SRAM or Static Random Access Memory is larger and faster and they will hold their contents indefinitely without external intervention. Both types of memory are subject to radiation effects.

[009] Most single event upset tolerant SRAM cells (hereinafter "cells") are clocked, D-type latches, which is to say that they obey the logical flow shown in Table 1. In short, when Clock is low, Next State equals Previous State. When Clock is High, Next State equals Data. *Per se*, there is nothing wrong with a D-type latch. It is the single most common type of latch since the dawn of the ASIC age. It is not the only type of latch however.

Table 1: Logical Flow of a Clocked, D-Latch

Clock	Input Data	Present State	Next State
0	0	0	0
0	0	1	1
0	1	0	0
0	1	1	1
1	0	0	0
1	0	1	0
1	1	0	1
1	1	1	1

[010] Another common type of latch is the SR or Set-Reset Latch. These latches obey the logical flow shown in Table 2. In short, when Set is active and Reset is inactive, regardless of the present state, the latch changes its state to a 1. When Reset is active and Set is inactive, regardless of the present state, the latch changes its state to a 0. When Set and Reset are both inactive, the latch holds the present state. Finally, Set and Reset are not allowed to be active simultaneously. Note that in these preceding sentences, Set and Reset are referred to as being either “active” or “inactive” rather than explicitly “1” or “0”. This is the concept of positive logic or negative logic and it is important for SR-Latches. Positive Logic means a 1 is active and a 0 is inactive. Negative Logic means a 0 is active and a 1 is inactive. Therefore, Table 2 actually shows the Logical Flow of a Positive Logic SR-Latch. The Logical Flow of a Negative Logic SR-Latch is identical except that a 1 is substituted for every 0 in both the S and R columns (but not the Present State or Next State columns) and a 0 is substituted for every 1 in both the S and R columns (but not the Present State or Next State columns).

Table 2: Logical Flow of an SR-Latch
(Positive Logic)

S	R	Present State	Next State
0	0	0	0
0	0	1	1
0	1	0	0
0	1	1	0
1	0	0	1

1	0	1	1
1	1	0	U
1	1	1	U

[011] Two fundamental building blocks of logic design are the Nand gate and the Nor gate. The Nand or “not and” gate obeys the logical flow shown in Table 3. The Nor or “not or” gate obeys the logical flow shown in Table 4.

Table 3: Logical Flow of a Nand Gate

A	B	A AND B	NAND(A,B)
0	0	0	1
0	1	0	1
1	0	0	1
1	1	1	0

Table 4: Logical Flow of a Nor Gate

A	B	A OR B	NOR(A,B)
0	0	0	1
0	1	1	0
1	0	1	0
1	1	1	0

[012] In logic design, a negative logic canonical SR flip-flop is formed by cross-coupling Nand gates as shown in Figure 1A. A canonical positive logic SR flip-flop is formed by cross-coupling Nor gates as shown in Figure 1B.

[013] SR flip-flops are considered the fundamental building blocks of sequential design (i.e. logic design with memory). D-latches are common in modern ASIC design because 1) the specialized computer industry generally want to latch and hold data and that is what a D-latch does and 2) D-latches can easily be designed in modern integrated circuit processes. SR latches are more fundamental than D-latches, however, because you can convert an SR-latch into a D-latch with one external gate, but you cannot convert a D-latch into an SR latch. You can convert an SR-latch into a clocked D-latch with three external

gates. In short, an SR-latch can be converted into any other type of latch with a simple application of external logic. From a logic designer's point of view, the SR latch is easily the most flexible type of latch available.

[014] Although there are two categories of radiation effects, total dose and single event, neither category are necessarily lumped together. There are instances when applications require single event immunity but not necessarily total dose immunity (such as a device that is only going to be exposed to radiation for a short time (e.g., X-ray detectors for medical imaging) and there are instances when applications require total dose immunity but not single event immunity. Nevertheless, it is most typical that a device be both total dose and single event tolerant. Unfortunately, many existing single event upset tolerant SRAM cells were designed for rad hard processes and they accomplish their SEU tolerance through highly specific transistor ratioing. This is to say that, in order for the circuits to function properly, certain transistors must be made weak and others must be made very strong. This adjusting of transistor strength is called "transistor ratioing" because the ratio of the size of two transistors determines their relative strength.

[015] As stated earlier, radiation tolerant design techniques in deep submicron processes are very effective, but they dramatically limit a designer's freedom to ratio his or her transistors and because of that, they also limit the number of SEU tolerant architectures that can be designed using radiation tolerant techniques. Some existing cells can be re-designed such that the burden of ratioing is born entirely by the p-type transistors, which are unaffected by the limitations imposed by radiation tolerant layout techniques. If a particular SEU tolerant architecture requires ratioing of its n-type transistors, however, then the chances are very good that that SEU tolerant architecture simply cannot be realized in a modern, cost-effective integrated circuit process. Moreover, if a cell requires ratioing to accomplish its objectives (even ratioing of its p-type transistors), then the speed, size, power consumption, and, ultimately, SEU tolerance of that cell will be

intimately related to the ratios chosen by the designer. This will be an issue whenever the device is scaled from one technology to another. Scaling from one process to another, (e.g., changing from 0.25 μ m to 0.18 μ m), can be problematic. Scaling problems are rarely insurmountable, but improperly scaled circuits are often the cause of failure in technology transfers. Few cells can be designed exclusively with minimum-sized transistors.

[016] Many cells require that the internal state of the cell be *overdriven* by external circuitry. For example, the DICE cell 200, which is labeled as "prior art" and is illustrated in Figure 2 shows that either transistor P2 (if the cell is holding a 1) or transistor N2 (if the cell is holding a 0) are driving Node A. Similarly, either transistor P4 or transistor N4 is driving Node B. When CLK is active, both Node A and Node B will be connected to Node D, and whatever external circuit is driving Node D will have to overcome the strength of the transistors driving Nodes A and B if it is to change the internal state of the DICE cell. This phenomenon is called overdriving. First when circuits must be overdriven, it underscores the necessity of transistor ratioing.

[017] External transistors must be more powerful (i.e., larger) than the transistors inside the cell. This can be troublesome in a shift register configuration or even a master-slave flip-flop configuration when one cell is driving another of the same type. If both the master and the slave are of the same type, then, by definition, the transistors in the external circuitry (the master) are not larger than the transistors inside the cell (the slave). Second, overdriving requires power when changing a state. The external transistors must drive the internal nodes to the reverse condition even though the internal transistors are trying to maintain their original condition. Accordingly, the power and ground are briefly shorted to one another through the internal and external transistors.

[018] Most cells cannot be asynchronously set or reset without undesirable modifications to their internal structure. In the past, if a set or a reset were

required, they were carried out synchronously - in other words, in the presence of a clock. This is not always the best approach for system designs. In fact, many systems require considerable work to guarantee a synchronous reset. Moreover, in the absence of a clock, a synchronously reset system cannot be reset. Therefore, if the clock itself is the problem, there is no way of recovering to a known state. Asynchronous sets and resets are, by a wide margin, the preferred approach by many organizations working in high radiation environments, and virtually all industrial applications in non-radiation environments.

[019] Most existing SEU tolerant cells perform the job they are designed to do, to a greater or lesser degree. In other words, they store data and they mitigate single event upsets. All cells, however, suffer from limitations. It would therefore be desirable to have SEU tolerant circuits that are more flexible logically, require no transistor ratios and could be designed in the minimum sized transistors available to any process, are designable in either specifically Rad hard processes or standard commercial processes or standard commercial processes using radiation tolerant layout techniques, are inherently scalable from process to process, require no overdriving of its internal state, and permit asynchronous sets and resets.

SUMMARY OF THE INVENTION

[020] It is a feature of the present invention to provide a single event upset (SEU) tolerant SR-latch.

[021] It is a feature of the present invention that the SEU tolerant SR-latch can be fabricated in any modern integrated circuit process that provides complementary transistors. It can be designed for rad hard processes or not. If commercial, non-rad hard processes are used, it can be designed using radiation tolerant layout techniques or standard rectangular design. It can also be used in Silicon-Germanium or Gallium-Arsenide processes, as well, provided complementary transistors are available.

[022] It is a feature of this present invention its layout is flexible. In its implementation, it most closely resembles modern CMOS design. In other words, all inputs are transistor gates. All outputs are transistor drains. Circuit behavior arises from the use of complementary transistors (i.e. one n-type and one p-type transistor gate is tied to each input). Circuit behavior is not dependent on the relative strengths of different transistors within the circuit. Therefore, minimum sized transistors – however that is defined by the application - can always be used. No scaling is required in order to make the design functional. Scaling of n-transistors relative to p-transistors will adjust the rise and fall time of the cell, but will not ultimately affect the function of the cell. Finally, if desired by a user, the entire Seuss Cell can be scaled to adjust its drive capacity or propagation delay or physical size, but, again, this will not ultimately affect the function of the cell.

[023] It is another feature of this present invention that it is logically flexible. Where the present invention is configured as an SEU tolerant SR flip-flop, it can be converted into any known type of latch (e.g. SR latch, D-latch, clocked D-latch, T-flip-flops, JK flip-flops, etc.) by simple applications of external logic and

without altering the internal architecture. This has two benefits. First, the type of latch available to the designer no longer limits designs. Second, the SEU tolerance of the register is not affected by the addition of external logic. The SR latch has essentially the same SEU tolerance as the clocked D-latch and the JK flip-flop.

[024] It is yet another features of the present invention that it is inherently scalable from one process to another. It does not matter what size the internal transistors of the present invention are; therefore, it does not matter what process they are designed in.

[025] It is yet another feature of the present invention that cells not require overdriving.

[026] It is yet another feature of the present invention that, from the perspective of a designer, it is reliable and predictable. When overdriving is required, process variations can render a design non-functional. In the present invention, however, changing the inputs is guaranteed to change the outputs because all inputs are gates and overdriving is not required. The change of output is only a matter of time relative to the change of input. The time required to do this is well and reliably predicted by modern Computer-Aided Design (CAD) software. Therefore, the performance of the present invention can always be reliably predicted before a company spends the money to fabricate a design.

[027] It is also another feature of this present invention that it behaves in all ways as an SR-flip flop. Therefore, there are two Seuss Cells – one that behaves as a negative-logic, cross-coupled Nand Gate SR-latch and one that behaves as a positive-logic, cross-coupled Nor Gate SR-latch.

[028] It is a feature of this present invention that it can be set or reset either synchronously or asynchronously, as the designer desires. This is an application

of external logic around an SEU tolerant SR-flip flop. The SEU tolerance of the cell is unaffected by this.

[029] It is a feature of this present invention that, because asynchronous sets and resets are possible, external, and redundant circuitry with auto-correction can be easily added to this present invention to increase its SEU tolerance even further.

[030] Additional features will be understood after reading the present description.

BRIEF DESCRIPTION OF THE DRAWINGS

[031] FIG. 1A, illustrates a canonical negative logic SR flip-flop is formed by cross-coupling Nand gates as shown in FIG. 1A;

[032] FIG. 1B, illustrates a canonical positive logic SR flip-flop is formed by cross-coupling Nor gates as shown in FIG. 1B;

[033] FIG. 2, labeled as Prior Art, illustrates schematic circuitry for a DICE cell, which is a commonly known SEU tolerant clocked D-latch;

[034] FIG. 3 illustrates schematic circuitry for a semiconductor cell referred to as a SEUSSNor and designed in accordance with embodiments of the present invention, and which behaves like an SEU tolerant positive-logic SR-latch formed from cross-coupled Nor Gates;

[035] FIG. 4 illustrates schematic circuitry for a SEUSSNor in the Reset Condition;

[036] FIG. 5 illustrates schematic circuitry for a SEUSSNor in the Set Condition;

[037] FIG. 6 illustrates schematic circuitry for a SEUSSNor in the Hold Condition;

[038] FIG. 7 illustrates schematic circuitry for a semiconductor cell referred to as a SEUSSNand and designed in accordance with embodiments of the present invention, and which behaves like an SEU tolerant negative-logic SR-latch formed from cross-coupled Nand Gates;

[039] FIG. 8 illustrates schematic circuitry for a SEUSSNand in the Reset Condition;

[040] FIG. 9 illustrates schematic circuitry for a SEUSSNand in the Set Condition;

[041] FIG. 10 illustrates schematic circuitry for a SEUSSNand in the Hold Condition;

[042] FIG. 11a-d illustrates sequential creation of a SEU tolerant SR-latch;

[043] FIG. 12 illustrates a schematic diagram of a model for a canonical Triple Redundant SR-latch;

[044] FIG. 13 illustrates a more sophisticated model of a triple redundant SEU tolerant SR-latch;

[044] FIG. 14 illustrates a simplified block diagram for a triple redundant SEU tolerant SR-latch with correction; and

[045] FIG. 15 illustrates another triple redundant SEU tolerant SR-latch with correction.

DETAILED DESCRIPTION OF EMBODIMENTS

[046] A schematic diagram for a single event upset tolerant positive logic SR flip-flop 300 is shown in Figure 3 along with the canonical schematic 310 it emulates and a table 320 of the logic it performs. Since this SEUSS Cell emulates a cross-coupled Nor Gate SR flip-flop, it is called a SEUSSNor. According to the schematic, a cell can be provided having inputs S and R. Inputs S and R only drive the gates of transistors (N1, P1), (N3, P3), (N5, P5), and (N7, P7).

[047] External circuitry driving the cell cannot possibly experience any “back drive” (i.e., no current is driven back out the inputs by the SEUSSNor towards the external circuitry) because CMOS gates are insulators. Moreover, regardless of how weak the external circuitry is and regardless of how strong the SEUSSNor’s internal circuitry is made, the next state is the inevitable result of the inputs only. Stronger internal circuitry simply increases the input capacitance of the SEUSSNor. Weaker external circuitry simply increases the time required by the external circuitry to charge the input capacitance of the SEUSSNor. In either case, the SEUSSNor must ultimately respond to the change in input. It is only a matter of time. Because the inputs are gates, the SEUSSNor, unlike existing SEU tolerant SRAM cells, never actively prevents a state change from occurring. Back drive has been eliminated.

[048] The complementary nature of the input transistor pairs eliminates overdrive:

- When S is a logical 1, N1 is on and P1 is off. Similarly, N5 is on and P5 is off.
- When S is a logical 0, N1 is off and P1 is on. Similarly, N5 is off and P5 is on.

- When R is a logical 1, N3 is on and P3 is off. Similarly, N7 is on and P7 is off.
- When R is a logical 0, N3 is off and P3 is on. Similarly, N7 is off and P7 is on.

[049] Referring to FIG. 4 a SEUSSNor 400 under a Reset ($S=0$ and $R=1$) is shown. Transistors that are off (open) under these conditions (N1, N5, P3, and P7) have been removed from FIG. 3. Transistors that are on (closed) under these conditions (P1, P5, N3 and N7) have been replaced with wires. It is easy to see that under these conditions, nodes Q and Q2 are immediately pulled to ground (logical 0). Moreover, nothing can prevent those nodes from being pulled to ground because transistors P3 and P7 (which are off) cut those nodes away from any transistors that might try to pull those nodes to a logical 1. Once Q and Q2 are at a logical 0, transistors N2 and N6 are turned off while transistors P2 and P6 are turned on, pulling nodes Qbar and Qb2 high without opposition. With these last two nodes pulled to a logical 1, N4 and N8 are turned on and P4 and P8 are turned off, locking the new state ($Q=0$, $Qbar=1$), as required by the Reset.

[050] Referring to FIG. 5 a SEUSSNor under a Set ($S=1$ and $R=0$) is shown. Transistors that are off (open) under these conditions (P1, P5, N3, and N7) have been removed from FIG. 5. Transistors that are on (closed) under these conditions (N1, N5, P3 and P7) have been replaced with wires. It is easy to see that under these conditions, nodes Qbar and Qb2 are immediately pulled to ground (logical 0). Moreover, nothing can prevent those nodes from being pulled to ground because transistors P1 and P5 (which are off) cut those nodes away from any transistors that might try to pull those nodes to a logical 1. Once Qbar and Qb2 are at a logical 0, transistors N4 and N8 are turned off while transistors P4 and P8 are turned on, pulling nodes Q and Q2 high without opposition. With these last two nodes pulled to a logical 1, N2 and N6 are turned on and P2 and P6 are turned off, locking the new state ($Q=1$, $Qbar=0$), as required by the Set.

[051] Referring to FIG. 6 a SEUSSNor under a Hold ($S=0$ and $R=0$) is shown. If both S and R are set to Zero, then $N1$, $N3$, $N5$, and $N7$ are all cut off. Meanwhile, $P1$, $P3$, $P5$, and $P7$ are all shorted. Note that under these conditions, the SEUSSNor now actually resembles the DICE cell (Figure 2) minus its input transistors. If Q is a One, then so is $Q2$, and $Qbar$ and $Qbar2$ are Zeros. Under these conditions, $P6$ and $P2$ are cut off, severing Nodes $Qbar$ and $Qbar2$ from power. Meanwhile, $P4$ and $P8$ are shorted, holding Q and $Q2$ as logical Ones. Also, $N4$ and $N8$ are cut off, severing Q and $Q2$ from ground while $N2$ and $N6$ are shorted to ground holding $Qbar$ and $Qbar2$ as logical Zeros. In other words, if Nodes Q and $Q2$ are both logical Ones, then they are held as logical Ones when S and R are both Zeros. Similarly, if Nodes Q and $Q2$ are both logical Zeros, then they are held as logical Zeros when S and R are both Zeros.

[052] If both S and R of a SEUSSNor are set to One, then there are multiple shorts from power to ground, and it is impossible to predict what state the circuit is in. This is an unknown state.

[053] From the preceding paragraphs, it is obvious that under all conditions the SEUSSNor cell obeys the canonical form of a cross-coupled Nor Gate, positive-logic SR flip-flop depicted in the table embedded within FIG. 3. Assuming that the SEUSSNor is holding a logical 1 (i.e. $Q=1$, $Qbar=0$, $Q2=1$, and $Qb2=0$), and that there is upset as shown in FIG. 6 by the lightening bolt 610, the upset can deposit charge on $Qb2$ that would pull it up or down in voltage. Of course, an upset that pulls $Qb2$ down would have no effect on the state of the SEUSSNor because, under the present assumptions, $Qb2$ is already low. Several things happen, however, if the upset tries to pull $Qb2$ up. Transistor $N6$ will immediately attempt to pull $Qb2$ back down. Moreover, the gate of transistor $N6$ is controlled by node $Q2$. $Q2$ itself is controlled by transistors $P8$ and $N8$. The gate of $N8$ is unaffected by the upset and $N8$ will remain cut off (the gate of $N8$ is controlled by $Qbar$, which is a 0). $Qb2$, the node that is being upset, controls the gate of $P8$. If $Qb2$ is low, $P8$ actively pulls $Q2$ to high. If $Qb2$ is high, $P8$ is cut off, and nothing

pulls Q2 high. Since this upset is driving Qb2 high, P8 will be cut off. The voltage value of node Q2 will remain unchanged (high) because nothing is pulling it low and it is that voltage on Q2 that will continue to keep transistor N6 alive and restoring the upset Qb2 back to its nominal value. Similarly, the voltage on Qb2 controls the gate of N4. If Qb2 is low, N4 is cut off. If Qb2 is high, N4 actively tries to pull node Q to ground. However, P4 is still on and controlled by Qbar, which is unaffected by the upset. Therefore, the voltage value of node Q will change but it will move from its nominal value slowly, under the conflicting influence of both N4 and P4.

[054] The single event upset, on the other hand, is a rapid event, and N6 will be restoring Qb2 to its nominal value faster than Q will be moving away from its nominal value. Moreover, as the upset is restored through N6 and Qb2 is returned to its nominal value, transistor N4 will become weaker and weaker until it is finally cut off. Then P4 will restore Q to its nominal value, and the upset will be mitigated.

[055] The internal transistors of a SEUSSNor (N1, P1), (N2, P2), (N3, P3), (N4, P4), (N5, P5), (N6, P6), (N7, P7), and (N8, P8) can be made as large or as small as desired. In short, the unique cell design set forth herein in accordance with features of the present invention requires no transistor ratios and could be designed in the minimum sized transistors available to any process, is alternatively designable in either specifically rad-hard processes, standard commercial processes or standard commercial processes using radiation tolerant layout techniques, is inherently scalable from process to process, and requires no overdriving of its internal state.

[056] A schematic diagram for a single event upset tolerant negative logic SR flip-flop 700 is shown in FIG. 7 along with the canonical schematic 710 it emulates and a table 720 of the logic it performs. This SEUSS Cell is called the SEUSSNand because it emulates a cross-coupled Nand Gate SR flip-flop.

According to the schematic, a cell can be provided having inputs S and R. Inputs S and R only drive the gates of transistors (N1, P1), (N3, P3), (N5, P5), and (N7, P7). Since CMOS gates are insulators, external circuitry driving the cell cannot possibly experience any "back drive" (i.e. no current is driven back out the inputs by the SEUSSNor towards the external circuitry). Moreover, regardless of how weak the external circuitry is and regardless of how strong the SEUSSNand's internal circuitry is made, the next state is the inevitable result of the inputs only. Stronger internal circuitry simply increases the input capacitance of the SEUSSNand. Weaker external circuitry simply increases the time required by the external circuitry to charge the input capacitance of the SEUSSNand. In either case, the SEUSSNand must ultimately respond to the change in input. It is only a matter of time. Because the inputs are gates, the SEUSSNand, unlike existing SEU tolerant SRAM cells, never actively prevents a state change from occurring. Back drive has been eliminated.

[057] The complementary nature of the input transistor pairs eliminates overdrive.

- When S is a logical 1, N1 is on and P1 is off. Similarly, N5 is on and P5 is off.
- When S is a logical 0, N1 is off and P1 is on. Similarly, N5 is off and P5 is on.
- When R is a logical 1, N3 is on and P3 is off. Similarly, N7 is on and P7 is off.
- When R is a logical 0, N3 is off and P3 is on. Similarly, N7 is off and P7 is on.

[058] Referring to FIG. 8 a SEUSSNand 800 under a Reset (S=1 and R=0) is shown. Transistors that are off (open) under these conditions (P1, P5, N3, and N7) have been removed from the figure. Transistors that are on (closed) under these conditions (N1, N5, P3 and P7) have been replaced with wires in the figure. It is easy to see that under these conditions, nodes Qbar and Qb2 are

immediately pulled to power (logical 1). Moreover, nothing can prevent those nodes from being pulled to power because transistors N3 and N7 (which are off) cut those nodes away from any transistors that might try to pull those nodes to a logical 0. Once Qbar and Qb2 are at a logical 1, transistors P2 and P6 are turned off while transistors N2 and N6 are turned on, pulling nodes Q and Q2 low without opposition. With these last two nodes pulled to a logical 0, P4 and P8 are turned on and N4 and N8 are turned off, locking the new state ($Q=0$, $Qbar=1$), as required by the Reset.

[059] Referring to FIG. 9 a SEUSSNand 900 under a Set ($S=0$ and $R=1$) is shown. Transistors that are off (open) under these conditions (N1, N5, P3, and P7) have been removed from FIG. 9. Transistors that are on (closed) under these conditions (P1, P5, N3 and N7) have been replaced with wires. It is easy to see that under these conditions, nodes Q and Q2 are immediately pulled to power (logical 1). Moreover, nothing can prevent those nodes from being pulled to power because transistors N1 and N5 (which are off) cut those nodes away from any transistors that might try to pull those nodes to a logical 0. Once Q and Q2 are at a logical 1, transistors P4 and P8 are turned off while transistors N4 and N8 are turned on, pulling nodes Qbar and Qb2 low without opposition. With these last two nodes pulled to a logical 0, P2 and P6 are turned on and N2 and N6 are turned off, locking the new state ($Q=1$, $Qbar=0$), as required by the Set.

[060] Referring to FIG. 10 a SEUSSNand 1000 under a Hold ($S=1$ and $R=1$) is shown. If both S and R are set to Zero, then P1, P3, P5, and P7 are all cut off. Meanwhile, N1, N3, N5, and N7 are all shorted. Note that under these conditions, the SEUSS Cell now actually resembles the DICE cell (FIG. 2) minus its input transistors. If Q is a One, then so is Q2, and Qbar and Qbar2 are Zeros. Under these conditions, N6 and N2 are cut off, severing Nodes Q and Q2 from ground. Meanwhile, N4 and N8 are shorted, holding Qbar and Qb2 as logical Ones. Also, P4 and P8 are cut off, severing Qbar and Qb2 from power while P2 and P6 are shorted to power holding Q and Q2 as logical 1s. In other words, if

Nodes Q and Q2 are both logical Ones, then they are held as logical Ones when S and R are both Zeros. Similarly, if Nodes Q and Q2 are both logical Zeros, then they are held as logical Zeros when S and R are both Zeros.

[061] If both S and R of a SEUSSNand are set to Zero, then there are multiple shorts from power to ground, and it is impossible to predict what state the circuit is in. This is an unknown state.

[062] From the preceding paragraphs, it is obvious that under all conditions the SEUSSNand cell obeys the canonical form of a cross-coupled Nand Gate, negative-logic SR flip-flop depicted in the table embedded within Figure 7. Assuming that the SEUSSNand is holding a logical 1 (i.e. $Q=1$, $Qbar=0$, $Q2=1$, and $Qb2=0$), and that there is upset as shown in the figure by the lightening bolt, the upset can deposit charge on Qb2 that would pull it up or down in voltage. Of course, an upset that pulls Qb2 down would have no effect on the state of the SEUSSNand, because under the present assumptions, Qb2 is already low. If, however, the upset tries to pull Qb2 up, several things happen. Transistor N8 will immediately attempt to pull Qb2 back down. Moreover, the gate of transistor N8 is controlled by node Q. Q itself is controlled by transistors P2 and N2. The gate of N2 is unaffected by the upset and N2 will remain cut off (the gate of N2 is controlled by Qbar which is a 0). Qb2, the node that is being upset, controls the gate of P2. If Qb2 is low, P8 actively pulls Q2 to high. If Qb2 is high, P8 is cut off, and nothing pulls Q high. Since this upset is driving Qb2 high, P8 will be cut off. The voltage value of node Q will remain unchanged (high) because nothing is pulling it low (N2 is cut-off) and it is that voltage on Q that will continue to keep transistor N8 alive and restoring the upset Qb2 back to its nominal value. Similarly, the voltage on Qb2 controls the gate of N6. If Qb2 is low, N6 is cut off. If Qb2 is high, N6 actively tries to pull node Q2 to ground. Meanwhile, the upset on Qb2 will try to turn transistor N6 on. However, P6 is still on and controlled by Qbar, which is unaffected by the upset. Therefore, the voltage value of node Q2 will change but it will move from its nominal value slowly, under the conflicting

influence of both N6 and P6. The single event upset, on the other hand, is a rapid event, and N8 will be restoring Qb2 to its nominal value faster than Q2 will be moving away from its nominal value. Moreover, as the upset is restored through N8 and Qb2 is returning to its nominal value, transistor N6 will become weaker and weaker until it is finally cut off. Then P6 will restore Q to its nominal value, and the upset will be mitigated.

[063] The internal transistors of a SEUSSNand (N1, P1), (N2, P2), (N3, P3), (N4, P4), (N5, P5), (N6, P6), (N7, P7), and (N8, P8) can be made as large or as small as desired. In short, the unique cell design set forth herein in accordance with features of the present invention requires no transistor ratios and could be designed in the minimum sized transistors available to any process, is alternatively designable in either specifically rad hard processes, standard commercial processes or standard commercial processes using radiation tolerant layout techniques, is inherently scalable from process to process, and requires no overdriving of its internal state.

[064] The beauty of an SR latch is two-fold. First, SR latches are the fundamental building block of sequential logic in that any latch can be created from an SR latch as shown in Figures 11a-d. With the addition of a single inverter, the SR latch becomes a D latch (a). With two AND gates and an inverter, it becomes a clocked, D latch (b). With two AND gates, it becomes a T or Toggle flip-flop (c). With two AND gates organized slightly differently, it becomes a JK-flip-flop (d). Two and-or-inverts plus an inverter turn the SR latch into a clocked, D latch with asynchronous sets and resets (e). By extension, the same can be done with SEUSS Cells. Above all, since the SEUSS cells are SEU tolerant and since these transformation do not affect the internal structure of the SEUSS Cells, the D-latch, clocked D-Latch, T flip-flop, JK flip-flop, and asynchronously settable and re-settable clocked D-Latch all have the same SEU tolerance. Finally and obviously, a second benefit of the SR latch is that is inherently capable of asynchronous sets and resets.

[065] The new SEUSSNor and SEUSSNand cell designs described herein are very robust in overall design and yield an SEU tolerance that is statistically identical to the SEU tolerance of a DICE Cell according to test results ($13.8 \pm 4.0 \times 10^{-18}$ cm/bit).

[066] Perhaps the most beneficial aspect of the SEU Registers is their flexibility. To illustrate this, the present inventor set out to develop something that could not be easily done with existing SEU tolerant registers, resulting in a Triple Redundancy circuits or TRed circuits.

[067] Triple Redundancy is a long established method for dealing with Single Event Upsets. Data is simultaneously stored in three identical memory cells. When it is read out, the contents of the three cells are compared and the output is determined by the rule of the majority – i.e. if there are two or three Ones, the output is a One; if there are two or three Zeros, the output is a Zero. A schematic model 1200 for the canonical Triple Redundant format of the present invention is illustrated in FIG. 12.

[068] Any storage cell can be used in the canonical form, whether it is a normal register or a cell designed in accordance with features of the present invention, or one of the other SEU tolerant cells. Under these conditions, reliability is expressed as

$$R_{NMR}(t) = \sum_{i=0}^{n-1} \frac{\lambda t^i}{i!} e^{-\lambda t}$$

where t is time, λ is the failure rate and n is the number of redundant storage cells – in this case 3. All that is improved in a Triple Redundant memory by the inclusion of an SEU tolerant cell is an improvement in the failure rate, λ .

[069] A more sophisticated implementation of Triple Redundancy in accordance with features of the present invention can be referred to as Triple Redundancy with Correction 1300, as illustrated in FIG. 13. In an ideal world, all three storage elements hold the same value – i.e., 1,1,1 or 0,0,0. In the presence of radiation, however, it is possible for the circuit to hold 2 Ones and a Zero or 2 Zeros and a One. Triple Redundancy with Correction allows the circuit to detect the presence of these error conditions and correct the cell back to its ideal state. Under these conditions, the circuit reliability improves to:

$$A(t) = R(t) + \int_0^t R(t-x) dM(x)$$

where t is still time, $R(t)$ is the circuit reliability from the previous equation and $M(x)$ is a function related to the repair time of the correcting circuit.

[070] Such a circuit shows a dramatic improvement in reliability for data that is being held for a considerable amount of time – i.e., times long with respect to the repair time. The notable thing about Triple Redundancy with Correction circuits is that they either require asynchronous sets and resets or they require a high speed “correction clock” whose job it is to periodically activate the clocked redundant storage latches to allow them to be corrected. Needless to say, the practical limitations associated a secondary correction clock are manifold. For example, correction can only happen in discrete units of time. Since single event upsets are random, it is possible that a second upset could occur before the first was corrected. Two upsets can prove fatal in a triply redundant system. Second, since there is more than one clock (i.e. the input or “main” clock and the correction clock), some considerable effort is required to coordinate the two clocks or ensure that such coordination is unnecessary. Thirdly, some considerable effort is necessary to ensure that “corrections” do not overwrite new input data. Simply stated, in the absence of asynchronous sets and resets, Triple Redundancy with Correction is not done. Triple redundancy with correction circuits are therefore a clear application of the unique registers of the

present invention. Not only will registers described herein improve the reliability of the storage cells, but they will also permit correction circuitry to repair errors.

[071] While developing this circuitry, it occurred to the present inventor that the flexibility of the SEU cells would actually allow the triple redundant with correction circuit itself to emulate either a positive logic or negative logic SR latch. If this were the case, then the triple redundant with correction logic could be repeated again and again, always resulting in a circuit that emulated an SR latch. Accordingly, an almost arbitrarily redundant circuit can be developed depending on the reliability being sought for a given application, and according to how much space can be committed for redundancy. No matter the number of redundancy sets used in a custom circuit, the resulting circuitry can still be converted it into whatever type of latch is required for an application by adding the appropriate external circuitry to the redundant circuitry. This is possible because SR latches are the fundamental building blocks of sequential circuitry.

[072] A simplified block diagram for a triple redundant SR latch 1400 with correction is illustrated in FIG. 14. It can be referred to as a TRed1. A second triple redundant SR latch with correction 1500 is illustrated in FIG. 14. It can be referred to as a TRed2. Both circuits emulate positive logic SR latches. Both can be made arbitrarily redundant by repeated nesting of redundant SR latches within larger redundant SR latches. TRed1 has a speed advantage since its output comes directly from one of the storage elements. Its triple redundancy is used solely for purposes of auto-correction. TRed2 has considerable SEU tolerance advantage since its output is truly a result of voting.

[073] The present invention does not require special transistor ratios and can be designed with any internal transistor sizes. The cells of the present invention can be designed in a rad hard process or a commercial process, either using radiation tolerant layout techniques or not. The cells are inherently scalable from one process to another. It does not matter what size the internal transistors are;

therefore, it does not matter what process they are designed in. An SEU cell in accordance with the present invention requires no overdriving and produces no back drive. The next state of an SEU Cell can be guaranteed from its inputs. The present invention provides cells that are inherently capable of asynchronous sets and resets.